

Quickstart Motion XS + Games Collection

INSTALLATION

Connect your Motion XS Controller to any USB 2.0 port of your personal computer. The driver will install automatically. Once installed, you may access your computer's control panel in order to calibrate the Motion XS Controller. In order to do so please double-click the icon entitled "Game Controllers" and select the Motion XS Controller. Click "Properties", followed by "Calibrate". Carry out the calibration process according to the on-screen instructions.

TROUBLESHOOTING

If you encounter any problems using the Snakebyte Motion XS Controller please read this section carefully before contacting our customer support or your dealer.

1. My Motion XS Controller does not work correctly at all.

Make sure the USB port you are using is USB 2.0 compliant. The Motion XS Controller is not USB 1.1 compatible. Please also make sure the USB port in use is installed correctly. Try to connect the controller to different USB ports in order to rule out any possible defects.

2. My game seems to receive input signals although I do not even touch the controller.

Use the Calibration option in your computer's control panel as described above in the Installation section of this manual.

3. The Games Collection is not running on my computer at all.

Make sure DirectX 9.0C is installed and try to run the Games Collection again. Please also make sure that your computer's hardware complies with the Games Collection's minimum requirements.